

Cleaning and care recommendations

for cementitious joint mortar of the SCHOMBURG product family CRISTALLFUGE

These cleaning and care instructions offer comprehensive help on all aspects of cleaning and caring for tile and natural stone coverings in conjunction with the cementitious joint mortars from the CRISTALLFUGE product family.

Removal of cement residue or construction dirt:

Facing material	SCHOMBURG joint mortar	Möller Chemie cleaning materials	Concentration/ mixing ratio
Tiles made of - porcelain stoneware - stoneware - earthenware - glass	CRISTALLFUGE CRISTALLFUGE-FLEX CRISTALLFUGE-PLUS CRISTALLFUGE-HF	HMK R183 Natural stone cleaner and cement residue Ex	Mixing ratio 1:2 - 1:10 dilute with water by parts by weight
Natural stone - insensitive to acid	CRISTALLFUGE-PLUS	HMK R183 Natural stone cleaner and cement residue Ex	Mixing ratio 1:2 - 1:10 dilute with water by parts by weight
Natural stone - sensitive to acid	CRISTALLFUGE-PLUS	HMK R155 basic cleaner - acid-free	Mixing ratio 1:2 - 1:10 dilute with water by parts by weight

Basic and maintenance cleaning:

Facing material	Basic cleaning	Maintenance cleaning
Coverings made of ceramic tiles and glass (private use)	Annual basic cleaning with HMK R157 intensive tile cleaner	Daily maintenance cleaning and care with HMK P315 stoneware care cleaner
Coverings made of ceramic tiles and glass (intensive use)	Basic cleaning at least every six months, if necessary, cleaning as required depending on use with HMK R157 intensive tile cleaner	Daily maintenance cleaning and care with HMK P315 stoneware care cleaner
Natural stone facings	HMK R155 basic cleaner - acid-free	Routine cleaning and care with HMK P324 gemstone soap

Commercial and industrial areas:

In the case of commercially or industrially used areas, we recommend cleaning and care in accordance with one on the use and cleaning and disinfection plan tailored to the requirements.

Important instructions:

- The product information and the safety data sheets of Möller-Chemie Steinpflegemittel GmbH and the SCHOMBURG GmbH & Co. KG must be observed.
- The cementitious SCHOMBURG joint mortar from the CRISTALLFUGE product family must be pre-dampened with sufficient water prior to cleaning and maintenance work in order to prevent medium or long-term damage from acid attacks After cleaning and care work has been carried out, the surfaces must be cleaned with clear water.
- Before starting cleaning and care work, sample surfaces must be created and their suitability checked.
- The cleaning and care instructions for the covering material must be observed and coordinated.